

# CAN'T TEAR 'EM

<b>BUNKER COAT</b>		<b>STYLE No: 36516</b>				
SIZE	S	M	L	XL	2XL	3XL
TO FIT CHEST:	90	95	100	105	110	115
<b>GARMENT MEASURE</b>						
UPPER CHEST	147	152	157	162	167	172
WAIST	123	128	133	138	143	148
HEM CIRC	120	125	130	135	140	145
CB TO SLV HEM	87.5	88.5	89.5	90.5	91.5	92.5
NECK TO SLV H	78.9	79.6	80.3	81	81.7	82.4
CUFF CIRC.	35.5	36	36.5	37	37.5	38

## BODY MEASUREMENTS

BODY MEASUREMENTS NOT TAKEN OVER CLOTHES.

**TO FIT CHEST:** FIRM UNDER ARMPITS AT AREA OF LARGEST CIRCUMFERENCE.

**SLEEVE LENGTH:** MEASURE FROM CENTRE OF BACK NECK AROUND RAISED BENT ELBOW TO WRISTBONE.

## GARMENT MEASUREMENTS

**UPPER CHEST:** MEASURE ACROSS GARMENT AT TOCM ABOVE SPLICE FROM FOLDED EDGE TO OTHER FOLDED EDGE. DOUBLE THE MEASUREMENT.

**CHEST:** MEASURE ACROSS GARMENT AT SPLICE FROM FOLDED EDGE TO OTHER FOLDED EDGE. DOUBLE THE MEASUREMENT.

**WAIST:** MEASURE ACROSS GARMENT AT TOP OF POCKETS FROM FOLDED EDGE TO OTHER FOLDED EDGE. DOUBLE THE MEASUREMENT.

**HEM CIRC:** MEASURE ACROSS BOTTOM OF GARMENT FROM FOLDED EDGE TO OTHER FOLDED EDGE. DOUBLE THE MEASUREMENT.

**CENTRE BACK LENGTH** MEASURE FROM CENTRE BACK NECK SEAM DOWN CENTRE BACK TO BOTTOM OF FINISHED HEM.

**CENTRE BACK TO SLEEVE HEM** MEASURE FROM CENTRE BACK NECK SEAM ALONG GARMENT DOWN SLEEVE TO BOTTOM OF FINISHED SLEEVE HEM.

**SIDE NECK TO SLEEVE HEM** MEASURE FROM NECK SEAM (AT POINT WHERE GARMENT FOLDS) ALONG GARMENT DOWN SLEEVE TO BOTTOM OF FINISHED SLEEVE HEM.

**CUFF CIRC:** MEASURE SLEEVE HEM FROM FOLDED EDGE TO OTHER FOLDED EDGE. DOUBLE THE MEASUREMENT.

