

CAN'T TEAR 'EM
MEASUREMENTS ARE IN CENTIMETRES

STYLE No: 33018

METRIC SIZE	WAIST BEFORE ELASTIC	WAIST AFTER ELASTIC	SEAT	INLEG	OUTLEG	FRONT RISE	KNEE	CUFF
TOLERANCE	20% REDUCTION REQUIRED	+3	+1.5	± 1.0	± 1.5	± 0.5	± 0.5	± 0.5
		-1.0	-1.0					
S	89.8	70	115	76	108	34	60	58
M	96.0	76	120	76	108	34	62	59
L	102.2	82	125	76	108	34	64	60
XL	108.4	88	130	76	108	34	66	60
2XL	114.6	94	135	76	108	34	68	60
3XL	120.8	100	140	76	108	34	70	60

METHOD OF MEASUREMENT

- WAIST:** Lay garment flat and measure along waist and double the measurement.
- SEAT:** Lay garment flat, measure up 10cm from front crutch seam. Measure across that point from side to side and double the measurement.
- INLEG:** Measure from the crutch seam along seam to hem edge.
- OUTLEG:** Measure from the top of the waistband along seam to hem edge.
- FRONT RISE:** Lay garment flat, measure from a point squared crutch (parallel with waistband) to the top of the waistband.
- KNEE:** Measure from crutch seam half the inleg measurement less 5cm. At that point measure from side to side and double the measurement.
- CUFF:** Measure along hem edge and double the measurement.